

TRANSPORTATION PERMIT

matter the first the second second					PERMIT VALID:			PERMIT NUMBER:			
Public Works - Street Maintenance					FROM:						
2005 HILLTOP CIR ROSEVILLE CA 95747						'					
IN COMPLIANCE WITH YOUR REQUEST AND SUBJECT TO ALL THE TERMS, CONDITIONS AND RESTRICTIONS WRITTEN BELOW AND THE ATTACHMENTS, PERMISSION IS HEREBY GRANTED TO:					MOVING AU	ITHOR	IZED:				
NAME					SATURDAY:				THIS PERMIT IS NOT VALID WITHOUT		
					ONDAI.	2		THE FOLLOWING ATTACHMENTS:			
ADDRESS 3					DAY:	2					
CITY/ST/ZIP					KNESS (CVC2	80):		·			
OFFICE PHONE NUMBER (INCLUDE AREA CODE) FAX NUMBER					NCLUDE AREA	4 COD	E)	X Conditions + Restrictions			
4 (SHOW A DESCRIPTION OF THE LOAD OR EQUIPMENT AND MODEL NO INCLUDE D					5			X Truck Route Map			
(SHOW A DESCRIPTION OF THE Authorization is granted for				RIVE:	TOW:		6				
			7								
DESCRIPTION OF HAULING	EQUIPMENT	Γ:		8	· · · · · · · · · · · · · · · · · · ·						
					HICLE 9 KINGPIN TO LAST AXLE:			10	COMB. VEHICLE	11	
AXLE NUMBER	1	2	3	4	5		6	7	8	9	
12 NUMBER TIRES PER											
13 AXLE DISTANCE BETWEEN AXLES	011480		<u> </u>								
14 WIDTH OF AXLES AT											
15 MAXIMUM ALLOWABLE WEIGHT					I						
	SIONS GREAT	TER THAN THO	SE SHOWN	BELOW OR V	WEIGHTS EXC	EEDIN	IG THOSE SHO	OWN ABOVE	ARE NOT AUTHOR	ZED	
LOADED HEIGHT: 16			1 7	DADED OVER	ALL LENGTH:	LO	ADED OVERH	^{ANG:} 19	WEIGHT CLASS:	20	
ORIGIN:	ORIGIN:					:					
21					22						
AUTHORIZED ROADS/STRI * OTHER AGENCY PERMIT		AYS									
				23							
				23							
PILOT CAR Y	e [No	24								
		-									
*SEE C	CONDITI	ONS & R	ESTRIC	CHONS	•						
CASH, CHECK, OR EXEMPT INFORMATION 25					ICANT SIGNATURE				DATE		
								26		27	
FEE OO NUM	MBER OF TR	RIPS		AUTHORIZ	ED CITY AG	ENT			DATE		
28		29									



Transportation Permit Application Reference Guide

- 1. **Permit Valid** List the inclusive dates that the permit will be valid.
- 2. **Moving Authorized -** Permission for authorized movement on Saturday, Sunday, or Darkness indicate with "yes" or "no" request next to each field.
- 3. **Name Fields -** Responsible person or company transporting the permit load or operating the vehicle. Permit is void if transferred or consigned.
- 4. **Office Phone Number** Contact telephone number where additional information can be obtained should a question arise during the processing of the application or the duration of the permit.
- 5. **Fax Number -** Where you would like the application returned.
- 6. Check Applicable Box: Haul, Drive, or Tow.
- 7. Description of the Load or Equipment Being Moved <u>FOR ANNUAL AND</u>
 <u>REPETITIVE MOVE PERMITS, THIS AREA MUST INCLUDE THE VEHICLE OR</u>
 <u>POWER UNIT LICENSE PLATE NUMBER.</u>
- 8. **Description of the Vehicle -** As stated in the vehicle inspection report issued by the State of California.
- 9. **Vehicle Width** <u>THIS ENTRY IS MANDATORY FOR ALL APPLICATIONS.</u> This is the width of the vehicle hauling the load or the width of a fixed load vehicle such as a crane. The entry should be in feet and inches.
- 10. **Kingpin to Last Axle** <u>THIS ENTRY IS MANDATORY FOR ALL APPLICATIONS.</u> An entry of "legal" is not acceptable for this section. For smaller trucks and trailers, this includes the hitch/ball joint combinations and pintle hooks to the center of the last axle. The following applies to most applications:
 - a. Single vehicle: Enter N/A.
 - b. Truck-Tractor/Motor truck/Semi-Trailer: Measure from the center of the kingpin to the center of the last axle.
 - c. Truck-Trailer: From the hitch, including draw bar length, to the center of the last axle.
 - d. Manufactured Housing: From the hitch, including draw bar length, to the center of the last axle.
 - e. Unladen 7/9-Axle Combinations: Measure from the center of the kingpin to the last axle of the load-carrying trailer.
- 11. Combination Vehicle Length <u>THIS ENTRY IS MANDATORY FOR ALL</u>

 <u>APPLICATIONS.</u> The actual length of the vehicle and/or vehicle combination from the most forward portion to the most rear portion. This length does *not* include overhanging portions of a load. (See Item #13 for use of the word "maximum.")

- 12. Number of Tires per Axle If the application does not involve extra legal weight, leave this section blank. <u>ALL EXTRA LEGAL WEIGHT APPLICATIONS MUST HAVE THIS</u> **SECTION COMPLETED.**
- 13. **Distance Between Axles** If the application does not involve extra legal weight, leave this section blank. **ALL EXTRA LEGAL WEIGHT APPLICATIONS MUST HAVE THIS SECTION COMPLETED.** Allowable weight is determined by the spacing between axles in a group. Generally, as the spacing increases, so does the allowable weight. Enforcement is to the nearest inch. Consequently, it is important that accurate distance in feet and inches are entered in these spaces. The first entry will be the spacing from the center of axle one (steering) to the center of axle two. The next entry will be from the center of axle two to the center of axle three and so on. Show the exact axle spacing with the corresponding maximum axle group weight.

Since allowable weight increases with spacing, the word "minimum" (abbreviated as "min") is acceptable with dimensions between axles and axle groups. Group weights will be assigned based upon these minimum dimensions.

When minimum dimensions are used for axle spacings, the word "maximum" (abbreviated as "max") must be used in Box #11 of the Combination Vehicle Length.

For applications with a kingpin entry, the word "maximum" (abbreviated as "max") should also be used in Box #10 for the Kingpin to Last Axle dimension.

- 14. Width of Axles at Tire Sidewall If the application does not involve extra legal weight, leave this section blank. ALL EXTRA LEGAL WEIGHT APPLICATIONS MUST HAVE

 THIS SECTION COMPLETED. For weight applications, provide the axle width measured to the nearest inch at the tire sidewalls. Dimensions should be in feet and inches.
- 15. **Maximum Allowable Weight** List the maximum allowable weight per axle.
- 16. **Loaded Height** List the height of the vehicle including the load.
- 17. **Loaded Width** List the width of the vehicle including the load.
- 18. **Loaded Overall Length** List the length of the vehicle including the load.
- 19. **Loaded Overhang** List the length of the overhang when loaded.
- 20. Weight Class Legal weight is the total unladen weight of the vehicle and the weight of the load not to exceed 80,000 pounds gross (CVC) 35550; 35551. <u>IF REQUESTING EXTRA LEGAL WEIGHT, SECTIONS 12 THRU 16 MUST BE COMPLETED.</u>
- 21. **Origin** List the Address/Source where the vehicle begins its route. If application is for an annual permit, list "Various."
- 22. **Destination** List the Address/Destination where the vehicle will end its route. If application is for an annual permit, list "Various."

23. **Authorized Roads/Streets/Highways** – List the intended travel route to destination. Reference the Truck Route Map published by City of Roseville to determine route. If application is for an annual permit, area may be left blank. This area will be filled in with:

"In any case, traveling to or from the point of delivery, pickup, service to or repair of the vehicle, the operator of the vehicle shall drive as far as possible upon and over a truck route."

- 24. **Pilot Car** Check appropriate box. Reference Conditions & Restrictions for Extra Legal Loads document for guidelines of when a pilot car is required.
- 25. **Cash, Check or On Account -** List "Check #," "Cash," or "On Account" (if you have a transportation permit drawdown account established with our division.)
- 26. **Applicant Signature** Sign and Date the application.
- 27. **Date** Date that the application is signed.
- 28. **Fee** Amount of individual permit. Single permits \$16.00; Annual/Repetitive Move permits \$90.00.
- 29. **Number of Trips** Single permit, list "1;" Annual or Repetitive Move permit, list "Multiple."